



IMPORTANT SAFETY INSTRUCTIONS AND PRECAUTIONS

- Read all instructions carefully before use.
- Retain manuals for future reference.
- Use this product only in the manner described.
- Only use a water-dampened soft-cloth to clean the surface of this product.
- The following will damage this product: any liquid such as water or moisture, extreme heat; cold; humidity, dusty or sandy environments.
- Only place this device on stable surfaces and ensure that any attached cables are secure and will not cause the device to fall.
- If charging is required, it is recommended to thoroughly charge electronic devices for the first time overnight. Subsequent charges can be as needed. During charging, or extended use, the product may become warm.
- There are no user serviceable parts in this product.
- Un-authorized attempts to dismantle or repair this product will void product warranty
- Using this device near other electronic devices may cause interference.

GETTING TO KNOW YOUR SPK-QC001 CLOCK RADIO	3
CLOCK AND AUDIO MODES	3
AUTO DIMMER LCD DISPLAY	4
SETTING THE TIME (From Clock Radio Mode)	4
12 HOUR/24 HOUR MODE (From Clock Radio Mode)	4
TEMPERATURE DISPLAY (From Clock Radio Mode)	4
WIRELESS CHARGING	4
USB CHARGING	4
AUDIO MODE - BLUETOOTH MODE	4
RECEIVING/REJECTING CALL - BLUETOOTH MODE	5
MUSIC CONTROLS VIA THE SPEAKER	5
AUDIO MODE - FM RADIO MODE	5
AUDIO MODE - AUX MODE	5
SETTING AN ALARM	5
SNOOZE	6
CHECK ALARM	6
TURNING ALARMS OFF (OR ON)	6

Contents include

SPK-QC001 Clock Radio, Mains Power Adapter, User Manual

GETTING TO KNOW YOUR SPK-QC001 CLOCK RADIO



1	Charging Pad	Wireless charging pad for compatible devices
2	Indicator Lamp	Indicator light while wireless charging
3	Volume/Next/Previous	Adjust volume and music tracks for playback
4	OK / Hands free	Confirm selections and answer phone calls via hands free
5	Alarm Settings	Set and check alarm settings
6	Mode / Power	Turn audio mode On or Off and change between alarm clock and Audio settings
7	Snooze	Delay alarms for 9 mins
8	Clock Display	Display for time, alarm and audio settings
9	USB Charging Sockets	Connect your portable device via a USB to begin charging
10	AUX Input	Connect your portable audio device via a 3.5mm audio cable

CLOCK AND AUDIO MODES

Your SPK-QC001 has two different modes; a normal clock mode and an audio mode. When in audio mode, you can access music for playback via Bluetooth, AUX (3.5mm Audio cable) or via FM Radio.

The Audio mode can be turned ON or OFF by pressing and holding the **MODE/POWER**

button. When audio mode is ON, press the **MODE/POWER** button to select the type of audio playback as displayed on screen: BT (Bluetooth), FM (FM Radio) or AUX (3.5mm Audio cable).

To turn OFF the audio mode press and hold the **MODE/POWER** button again until the audio mode icons (BT, or AUX or FM) disappear from screen. (You can now access the user settings for the alarm clock radio as described later on in this manual)

AUTO DIMMER LCD DISPLAY

Your SPK-QC001 has an auto dimming display, when in low light conditions such as next to your bed at night.

SETTING THE TIME (From Clock Radio Mode)

Press the **MODE** button. The hour digit will now blink

Set the hours by pressing the **- or +** buttons

Short press the **MODE** button again. The minute digit will now blink.

Set the minutes by pressing the **- or +** buttons again

Short press **MODE** or wait 15 seconds to return to the clock view

12 HOUR/24 HOUR MODE (From Clock Radio Mode)

Press and hold the **OK** button to switch from 12 hour mode to 24 hour mode

TEMPERATURE DISPLAY (From Clock Radio Mode)

To switch the temperature display from Celsius to Fahrenheit, press the **- button and the + button** at the same time (*The room temperature display is accurate to +/- 3 degrees*)

WIRELESS CHARGING

Note: First ensure wireless charging is turned on, on your compatible Qi enabled Smart Phone. (Refer to the end of this manual for various Qi enabled Smart Phones)

Place your Smart Phone on the center pad, at the top of your SPK-QC001. The indicator light will turn ON while charging.

Note: Due to the nature of wireless charging, devices may get warm to touch while charging. Wireless charging is unavailable in FM mode.

USB CHARGING

There are 3 USB ports at the front of the alarm clock. Simply connect your portable device using a USB cable to begin charging.

AUDIO MODE - BLUETOOTH MODE

- Press and hold the **MODE** button to enter the audio mode. The first **MODE** by default, is Bluetooth mode.

- You will see letters **BT** begin to blink on the LED display, followed by a confirmation sound that your SPK-QC001 is ready to pair.

- Turn on Bluetooth from your portable media device and search for your SPK-QC001. Then tap and pair.
- Once connected a second confirmation will sound and **BT** will stop flashing on screen. You can now begin music playback.
- To exit Bluetooth mode, long press the **MODE** button until **BT** disappears from the LED display and to be returned back to normal clock mode.

RECEIVING/REJECTING CALL - BLUETOOTH MODE

While in Bluetooth mode, press **OK** to accept a call

Press **OK** again to hang up from a call

Note: You can only reject a call from your device, not from the speaker

MUSIC CONTROLS VIA THE SPEAKER - BLUETOOTH MODE

Press the **OK** button to play or pause music playback

Press the **- button** to go to the previous song

Press and hold the **- button** to decrease volume

Press the **+ button** to go to the next song

Press and hold the **+ button** to increase volume

AUDIO MODE - FM RADIO MODE

- Use the **MODE** button to select **FM** mode.

- Press and hold the **OK** button to auto-search and store all available FM stations

- Press the **- or +** buttons to move between saved stations

- Press and hold the **- or +** buttons to change volume

- To exit **FM** mode, press and hold the **MODE** button until **FM** disappears from the LED display and to be returned back to normal alarm clock mode.

AUDIO MODE - AUX MODE

- Use the **MODE** button to select **AUX** mode.

- Use a 3.5mm audio cable to connect your portable media device to the AUX input - socket at the front of the speaker.

- To exit **AUX** mode, long press the **MODE** button until **AUX** disappears from the LED display and to be returned back to normal clock mode.

SETTING AN ALARM

Set alarm 1

- Press the **ALARM** button. The **ALARM 1** text and icon will appear. The **ALARM 1** time will begin to blink

- Press the **+ and - buttons** to adjust the hour. Press the **ALARM** button to move to minutes, using the same buttons to make adjustments.

- Press the **ALARM** button then the **- or + buttons** to choose buzzer (shown as Bu22) or FM radio (shown as the radio station frequency) as the alarm tone

- Press the **ALARM** button a last time to confirm and exit the alarm settings.
- The set time for Alarm 1 and the Alarm 1 icon/text will remain on screen.

Note: The last radio station you listened to will be the FM alarm tone

Set alarm 2

- After Alarm 1 has been set, press the **ALARM** button (5 times) until the **ALARM 2** icon and text appear on the screen.
- The Alarm 2 time will begin to blink.
- * *Follow on from the instructions above for **ALARM 1** to adjust the Alarm 2 time and settings.*

SNOOZE

Press the **SNOOZE** button to snooze an alarm for 9 minutes

When the alarm sounds, press the **ALARM** button to cancel the alarm and snooze

CHECK ALARM

- Press the **SNOOZE** button to check the **ALARM 1** time.
- The **ALARM 1** text will blink on screen and underneath it, the set time.
- Press the **SNOOZE** button to check the **ALARM 2** time.
- The **ALARM 2** text will blink on screen and above it, the set time.
- Press the **SNOOZE** button again to exit.

TURN ALARMS OFF (OR ON)

- Press the **SNOOZE** button. The **ALARM 1** text will blink
- Press and hold the **ALARM** button to turn ALARM 1 OFF (or conversely ON).
- The ALARM 1 icon will turn OFF (or conversely ON).
- Press the **SNOOZE** button again. The **ALARM 2** text will blink
- Press and hold the **ALARM** button to turn ALARM 2 OFF (or conversely ON).
- The **ALARM 2** icon will turn OFF (or conversely ON).
- Press the **SNOOZE** button a last time to exit the settings

Example Qi Charging Compatible Smart Phones

Google (LG)	Nexus4
	Nexus5
	Nexus7
HTC	Droid DNA (USA version)
	Rzound
	Butterfly (USA version)
	HTC 8X
	HTC 8XT
	Incredible 4G LTE
	M8
LEXUS	NX300h
LG	LG E960
	D1L
	LG Optimus G Pro E988
	G2 wireless charger PCB
	G3
	LTE2
Nokia	lumia830
	lumia920
	lumia820
	lumia1020
	lumia1520
	lumia930
	lumia Icon929
SAMSUNG	S6/S6 edge
SHARP	SH-07D
	SH-04D
	SH-02D
	SH-13C
Yota	Yota phone2
ZTE	Xperia Z2
	Grand S EXT

Warranty Against Defects

Laser Corporation Pty Ltd ("Laser") warrants your new product to be free from defects in materials and workmanship for 12 months, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. The benefit of this warranty is in addition to your rights under the Australian Consumer Law and to other rights and remedies of the consumer under a law in relation to the goods or services to which the warranty relates. Through a network of retailers and resellers, Laser will provide you with your choice of a repair, exchange (where possible) or refund (within Dead on Arrival period) for this product if it becomes defective within the warranty period. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse, normal wear and tear, neglect or improper storage. Please retain your receipt as proof of purchase. How to make a product warranty claim: Step 1: Find your receipt which proves the date of purchase. Where the date of purchase cannot be verified, your place of purchase or Laser will make an assessment based on the date of manufacture, the condition of the Laser Product and the type of defect. Step 2a): Contact your place of purchase. They will assess the nature of the fault and repair, replace or fund the product as per their store refund or warranty policy. Step 2b): If your place of purchase cannot be contacted, then you can contact Laser. Customer Service with details of your defective Laser Product: Phone: (02) 9870 3388; or Email: support@laserco.com.au or online www.laserco.com.au/warranty (click on "Consumers (End Users)"). Our business address is at 1/6-8 Byfield Street, North Ryde, NSW 2113. Step 3: Laser will issue you with a Return Authorisation (RA) number within 48 hours. When requested, send us the defective Product and a copy of your receipt. Laser will cover the cost of the return delivery. Step 4: Wait for us to contact you. Once we have received your defective Laser Product for inspection, we will inform you of our assessment of your claim within 7 days. When we contact you, we will firstly let you know whether you have a valid claim under this Warranty, and if so, we will inform you whether your defective Laser Product will be replaced or repaired, together with the number of days you can expect to wait to receive your replaced or repaired Laser Product. Step 5: For further details on warranty cover and returns, please check [Terms and Conditions for Warranty Returns](#) section on <http://www.laserco.com.au/warranty> Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.